




Build Limitless® Squat Stand

Installation Instructions

Tool List

- 15/16" Box End Wrench
- 15/16" Socket
- Ratchet or Impact Driver

Item #	Description	Qty.
1	Upright	2
2	Multi-Grip Pull-Up Bar	1
3	5/8" Nylock Nut	10
4	5/8" Flat Washer	8
5	5/8" x 4-1/2" Hex Bolt	8
6	Angled Foot	4
7	Floor Spreader Plate	1
8	5/8" x 4-1/4" Hex Bolt	2
9	J-Cup Pair	1



WARNING

- Read all assembly, installation and use instructions in this manual prior to using this equipment.
- Inspect equipment prior to use. DO NOT use if it appears damaged or inoperable
- Use equipment only for the intended use DO NOT modify the machine
- DO NOT attempt to fix broken equipment. Call or email PRx Performance for assistance.
- **SQUAT RACK MUST BE BOLTED TO THE GROUND**

Save this manual for future reference.

All questions, feedback, and return information should be sent to: support@prxperformance.com or call us at 1-701-566-0452

 WARNING: SERIOUS INJURY OR DEATH COULD OCCUR IF SAFETY PRECAUTIONS ARE NOT TAKEN.

042525_Rev. 1

Installation Instructions

Rack Assembly:

1. Attach Angled Feet (6) to the bottom of the Uprights (1) with the hardware shown. **Figure 1, Detail B**

Detail B

NOTE 1: Make sure numbers and PRx Logo are facing the front of the rack.

NOTE: Leave all hardware somewhat loose until the rack is completely assembled.

2. Attach Multi-Grip Pull-Up Bar (2) between the top of the Uprights (1) with hardware shown.

Figure 1, Detail A

3. Attach the Floor Spreader Plate (7) between the bottoms of the Uprights (1) with hardware shown. **Figure 1, Detail C**

4. Once all parts are assembled, stand rack upright and start tightening hardware from the ground up.




Figure 1

All questions, feedback, and return information should be sent to: support@prxperformance.com or call us at 1-701-566-0452